


Ice Cream Sandwich Maker Demo

1. Ice Cream Sandwich Maker is shipped in a box and poly bag with this orientation:



2. Disassemble all parts. There are three parts total 1) clear cylinder, 2) platform (white and gray in color) and 3) plunger (gray in color). Remove plunger from platform by gently pulling and twisting. *Tip: End of plunger with no logo fits onto bottom of platform. Logo end fits loosely onto bottom of platform and we do not recommend this fit.*



3. Place small end of clear cylinder on flat surface. Gently press platform into clear cylinder with flat side up (this is step 1 of Use and Care)



4. Place cookie, flat side up, on platform. If cookie is too large, place on Cutting board and trim off edges with large end of cylinder by pressing down over cookie (this is step 2 of Use and Care). *Tip: Remove platform from clear cylinder if cookie needs to be trimmed, then press platform back into cylinder when finished trimming.*



5. Scoop desired amount of ice cream (about 2 scoops) on cookie and spread evenly with back of Ice Cream Dipper. Top with second cookie, flat side down (this is step 3 of Use and Care).



6. To remove sandwich, place platform on top of plunger and push cylinder downward. *Tip: Wrap with plastic wrap and secure with Twixit! Clip.*

